



Internet-To-Go (MiFi)

The Verizon mobile Hotspot that keeps your tablet, laptop, smartphone, and other Wi-Fi enabled devices connected to the Internet. *This device does not filter content. Parents and caregivers are responsible for monitoring children's online activity.*

Using Your Wi-Fi Hotspot

- Press and hold **Power Button** on top of JetPack until **blue light blinks**
- Wait about 30 seconds for device to move through several screens
- Note the WiFi password taped to the front of the device

Linking Your Device And Wi-Fi Hotspot


iOS/ANDROID Mobile Devices

- Open Settings
- Open Wi-Fi
- Turn on Wi-Fi
- Choose your Wi-Fi name
- When prompted, type in Password displayed on Hotspot screen


LAPTOPS

- Click the Wi-Fi bar
- Open Wi-Fi networks
- Choose your Wi-Fi name
- When prompted, type in Password displayed on Hotspot screen

Universal Charging Cable



WARNING! Use only an approved charger to charge your Jetpack. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.



NOTE: Appearance of device might vary.

CAROUSEL ICONS

	Wi-Fi — View Wi-Fi Name/Password.
	Connected Devices — View currently connected/blocked device details.
	Data Usage — View data usage and billing cycle details.
	Settings — View/change basic Jetpack and Wi-Fi settings.
	Universal Charging — Displays universal charging status.
	Software Update — View current software version and check for updates.
	Messages — View/delete system messages.
	About Jetpack — Displays device details/Internet status.
	Help — Displays Help, Tips, and Advanced features.

MiFi Overview

